


Installation Guide



| | |
|----|-----|
| EC | REP |
|----|-----|

Company: E-CrossStu GmbH
 Address: Mainzer Landstr.69, 60329 Frankfurt am Main
 Mail: E-CrossStu@web.de

| | |
|----|-----|
| UK | REP |
|----|-----|

Company: YH Consulting Limited
 Address: C/O YH Consulting Limited Office 147, Centurion House,
 London Road, Staines-upon-Thames, Surrey, TW18 4AX
 Mail: H2YHUK@gmail.com



P66SZB

WARNING and CAUTION !!!

EN English

Please follow all safety operating procedures during installation. Pay attention to keep this product away from children.

DE Deutsch

Bitte beachten Sie während der Installation alle Sicherheitsvorschriften. Achten Sie darauf, dieses Produkt von Kindern fernzuhalten.

FR Français

Pendant l'installation, suivez toutes les procédures d'exploitation de sécurité. Prenez soin de garder ce produit loin des enfants.

IT Italiano

Si prega di seguire tutte le procedure operative di sicurezza durante l'installazione. Prestare attenzione a tenere questo prodotto lontano dai bambini.

ES Español

Durante la instalación, siga todos los procedimientos de operación de Seguridad. Preste atención a mantener este producto alejado de los niños.

NL Nederlands

Volg alle veiligheidsprocedures tijdens de installatie. Let op om dit product uit de buurt van kinderen te houden.

PL Polski

Podczas instalacji należy przestrzegać wszystkich procedur bezpieczeństwa. Zwróć uwagę, aby trzymać ten produkt z dala od dzieci.

CZ Čeština

Během instalace dodržujte všechny bezpečnostní provozní postupy. Věnujte pozornost tomu, aby tento výrobek udržel dál od dětí.


SE Svenska

Följ alla säkerhetsrutiner under installationen. Var uppmärksam på att hålla denna produkt borta från barn.

TR Türkçe

Lütfen kurulu sırasında tüm güvenlik işleme prosedürlerini takip edin. Bu ürünü çocuklardan uzak tutmak için dikkat et.

Please Read Carefully



Read all instructions carefully




Protect your eyes by wearing safety goggles



Keep the installation area free of clutter















We recommend two people for certain parts of the installation



Follow each step completely before starting the next step












Tools Needed(Prepared by Yourself)

| | | |
|--|---|--|
| <p>levelling instrument</p>  | <p>Stud Finder</p>  | <p>Tape measure</p>  |
| <p>Speed Square</p>  | <p>Marking tools</p>  | <p>Deep Socket Wrench</p>  |
| <p>Drill bits</p>  | <p>Electric drill</p>  | <p>Phillips screwdriver</p>  |
| <p>Combination Wrench</p>  <p>Two #13 wrenches.</p> | <p>Hammer</p>  <p>Rubber Hammer</p> | <p>Please have all of the above tools available before installation so that installation will be easier.</p>  |

IMPORTANT!


Check whether all the parts are complete after receiving the goods, if there are missing or damaged, please do not return the goods, contact your customer service, we will provide you with free replacement.

Packaging List (Easier installation by part number marking)


| | | | |
|--|--|---|--|
|  <p>Diagram showing the main assembly components, labeled A, consisting of two long metal rails with pre-drilled holes and mounting brackets.</p> |  <p>Diagram showing a package labeled B containing a small metal rail with four holes and four screws.</p> <p>x2</p> | | |
|  <p>Diagram showing two sets of rollers, labeled C, each consisting of a wheel and a mounting bracket.</p> <p>x2</p> |  <p>Diagram showing a package labeled D containing a long metal rod, two L-shaped brackets, and four screws.</p> <p>x1</p> |  <p>Diagram showing a package labeled E containing a hex nut, a threaded rod, a washer, and a screw.</p> <p>x6</p> |  <p>Diagram showing a small metal bracket, labeled F, with a hole and a notch.</p> <p>x6</p> |
|  <p>Diagram showing two long vertical metal brackets, labeled G, with a hole and a notch.</p> <p>G</p> |  <p>Diagram showing a package labeled H containing various screws, nuts, and washers.</p> <p>x1</p> |  <p>Diagram showing a package labeled I containing four screws.</p> <p>x1</p> | |
| |  <p>Diagram showing a package labeled J containing various screws and brackets.</p> <p>x1</p> |  <p>Diagram showing a package labeled K containing two metal brackets.</p> <p>x1</p> | |

Tips: Required Dimensions


6.6 FT Track Fits Max. Door Opening



6.6 FT Track Fits Door Panel Size




6.6 FT Track Installation Position



Before You Begin

Warning: Do not install the track directly on drywall or other walls which don't have enough weight capacity. If necessary, we recommend using a solid wood Header Board.

▲ Ensure That Your Wall Has Sufficient Load-bearing.



1 Check Your Wall



Check your shed roof construction before installing. Different constructions require different tools

Wood frame walls and gypsum board wall require the following tools :

(drilling steps on page 7-9)

Tools



Parts



Solid Brick Wall\Hollow Brick Wall\Concrete wall (drilling steps on pages 10-11) and cement wall require the following tools:

Tools


Parts



2 Pick Your Door Openg Direction

Open the door to the right

Open the door to the left




3 Check for level floor and center of track level

IMPORTANT!

★ To ensure that the door opens and closes prorerly, use a level to check the floor and center of track are level before installing and measuring.


★ Tracks that are not level can cause sliding doors to jam, or door panels to slide sideways




Step 1 Tracks Connection

① Arrange tracks by serial number


⚠ Wrong track orientation will not align the splice




② Connecting Segment Tracks



③ Put the pulley into the track



④ Install (D) (pulley stoppers) in the track




Step 2: Install the track ("Plasterboard Wall" and "Wood Frame Wall" installation process in P7-P9; "Concrete Wall" please check P10~P11)

The track installation process for gypsum board wall and wood framed walls is as follows.


(The header board needs to be prepared by yourself.)

- ① Before installation, please "Prepare a Backboard" (please refer to the following suggested backboard size) and some nails needed to fix the backboard.





Header board size: thickness: 25mm/1" width: 100mm/4" length=track

- ② After the backboard is ready, please determine the installation position.




- ③ Use the Stud Finder to determine the load bearing position

Gypsum board wall
(If the interior of the wall is made of wood load-bearing structure) needs to be installed with "Header board", and then continue to install this track.




The track installation process for gypsum board wall and wood framed walls is as follows.

④ Install the backboard.




⑤ Locate the holes position





The track installation process for gypsum board wall and wood framed walls is as follows.

⑥ Drill deep 50mm(2") holes with 3mm(1/8") power drill




⑦ Install Track




The track installation process for Solid Brick Wall\Hollow Brick Wall\Cement wall and cement wall is as follows.


① Locate the holes position



② Drill deep 50mm (2") holes with 15mm (19/32") power drill and put in the wood.




③ Mark and drill holes on wood plugs





The track installation process for Solid Brick Wall\Hollow Brick Wall\Cement wall and cement wall is as follows.

④ Drill deep 50mm(2") holes with 3mm(1/8 ") power drill




⑤ Install Track







Step3 Bottom Slotting of Door Panel and Hangers Installation

① Slot according to size at the bottom of the door.



If you have a floor guide that doesn't require slotting, you can ignore this step.




② Use a drill bit with a diameter of 11mm ($\frac{7}{16}$ ")to drill holes on the door panel as shown.




Step 4 Hanging the door



① Fine-tuning the front and rear positions of the door panels




② Tighten the screws in the picture




③ Use two wrenches, hold the top one stationary and tighten the bottom one.

Step 5 Install Floor Guide




Step 6 Slide the door on open status

Push the pulley stopper close to the pulley in shown ② use the Allen key screw up the pulley stop



Step7 Slide the door on close status

Push the pulley stopper close to the pulley in shown use the Allen key screw up the pulley stopper



Step8 Install the Track End Plug

