



Installation Guide



EC

REP

Company: E-CrossStu GmbH
 Address: Mainzer Landstr.69, 60329 Frankfurt am Main
 Mail: E-CrossStu@web.de

UK

REP

Company: YH Consulting Limited
 Address: C/O YH Consulting Limited Office 147, Centurion House,
 London Road, Staines-upon-Thames, Surrey, TW18 4AX
 Mail: H2YHUK@gmail.com



A00STS

WARNING and CAUTION !!!

EN English

Please follow all safety operating procedures during installation. Pay attention to keep this product away from children.

DE Deutsch

Bitte beachten Sie während der Installation alle Sicherheitsvorschriften. Achten Sie darauf, dieses Produkt von Kindern fernzuhalten.

FR Français

Pendant l'installation, suivez toutes les procédures d'exploitation de sécurité. Prenez soin de garder ce produit loin des enfants.

IT Italiano

Si prega di seguire tutte le procedure operative di sicurezza durante l'installazione. Prestare attenzione a tenere questo prodotto lontano dai bambini.

ES Español

Durante la instalación, siga todos los procedimientos de operación de Seguridad. Preste atención a mantener este producto alejado de los niños.

NL Nederlands

Volg alle veiligheidsprocedures tijdens de installatie. Let op om dit product uit de buurt van kinderen te houden.

PL Polski

Podczas instalacji należy przestrzegać wszystkich procedur bezpieczeństwa. Zwróć uwagę, aby trzymać ten produkt z dala od dzieci.

CZ Čeština

Během instalace dodržujte všechny bezpečnostní provozní postupy. Věnujte pozornost tomu, aby tento výrobek udržel dál od dětí.

SE Svenska

Följ alla säkerhetsrutiner under installationen. Var uppmärksam på att hålla denna produkt borta från barn.












TR Türkçe

Lütfen kurulu sırasında tüm güvenlik işleme prosedürlerini takip edin. Bu ürünü çocuklardan uzak tutmak için dikkat et.

Please Read Carefully

 <p>Read all instructions carefully</p>	 <p>Protect your eyes by wearing safety goggles</p>	 <p>Keep the installation area free of clutter</p>	 <p>We recommend two people for certain parts of the installation</p>	 <p>Follow each step completely before starting the next step</p>
--	---	--	--	---

Tools Needed(Prepared by Yourself)

<p>Tape measure</p> 	<p>levelling instrument</p> 	<p>Stud Finder</p> 
<p>Marking tools</p> 	<p>Speed Square</p> 	<p>Drill bits</p> 
<p>Electric drill</p> 	<p>Deep Socket Wrench</p> 	<p>Hammer</p> 
<p>Phillips screwdriver</p> 	<p>Please have all of the above tools available before installation so that installation will be easier.</p> 	


IMPORTANT!

Check whether all the parts are complete after receiving the goods, if there are missing or damaged, please do not return the goods, contact your customer service, we will provide you with free replacement.


Packaging List(Easier installation by part number marking)

Track and Track Accessories


The number of this part depends on the size you purchase, refer to attached table.




The number of this part depends on the size you purchase, refer to attached table.





The number of this part depends on the size you purchase, refer to attached table.



Hangers and Hangers Accessories




D



E



×1



F

×1

G



Tips: Required Dimensions

Track Fits Max. Door Opening

Top of the opening to ceiling clearance min.178mm(7")

Opening Max.

floor

Track lengths and applicable door opening widths

Track length	Max opening width
2FT\612mm	9inch\230mm
2.5FT\764mm	12inch\300mm
3FT\918mm	15inch\380mm
3. 3FT\1018mm	17inch\430mm
3. 5FT\1070mm	18inch\450mm
4FT\1222mm	21inch\530mm
4. 3FT\1324mm	23inch\580mm
5FT\1526mm	27inch\685mm
5. 21FT\1592mm	28inch\720mm
5. 7FT\1730mm	31inch\785mm
6FT\1830mm	33inch\835mm
6. 6FT\2034mm	37inch\940mm
7FT\2136mm	39inch\990mm
7. 3FT\2236mm	41inch\1040mm
7. 5FT\2288mm	42inch\1065mm
8FT\2440mm	45inch\1140mm

Track length	Max opening width
8. 3FT\2542mm	47inch\1190mm
9FT\2744mm	51inch\1290mm
9.6FT\2948mm	55inch\1395mm
10FT\3048mm	57inch\1450mm
10.6FT\3252mm	61inch\1550mm
11FT\3354mm	63inch\1600mm
11.5FT\3558mm	67inch\1700mm
12FT\3658mm	69inch\1750mm
12.6FT\3860mm	73inch\1850mm
13FT\3964mm	75inch\1900mm
13.6FT\4166mm	79inch\2000mm
14FT\4266mm	81inch\2055mm
15FT\4572mm	87inch\2210mm
16FT\4876mm	93inch\2360mm
18FT\5485mm	104inch\2640mm
20FT\6000mm	115inch\2920mm

Track Fits Door Panel Size

Opening width+ 80mm~100mm (3"~4")

floor

Door Panel Width:
Door Opening Width +80-100mm(3-4").

Door Panel Height:
Door Opening Height +25-50mm(1-2").

Door Panel Thickness:30–48mm(1-³/₁₆" ~1-⁷/₈").

Door Panel Weight :Max150kg (330 lbs)

Track Installation Position

Half length of the track

Half length of the track

Center of track

25mm(1")

Vertical centerline

10mm (³/₈") clearance between bottom door and floor

Bottom of floor to center of track= Door panel height+41mm(1-⁵/₈")

floor

Center of track position:

Door panel height+**41mm(1-⁵/₈")**

Vertical of track position:

Door frame edge+**25mm(1")**

Before You Begin

Warning: Do not install the track directly on drywall or other walls which don't have enough weight capacity. If necessary, we recommend using a solid wood Header Board.

▲ Ensure That Your Wall Has Sufficient Load-bearing.

Brick Walls : Solid Brick Wall	Hollow Brick Wall	Cement wall/Concrete Wall	Wooden Frame Wall	Gypsum Board Wall (If the interior of the wall is made of wood load-bearing structure) needs to be installed with "Header board", and then continue to install this track.	Gypsum Board Wall (If the interior of the wall is made of steel or iron) cannot be installed with this track.

1 Check Your Wall

Check your shed roof construction before installing. Different constructions require different tools


Wood frame walls and gypsum board wall require the following tools :

(drilling steps on page7-9)

Tools

Stud Finder 	levelling instrument 	Speed Square 	Tape measure 	Marking tools 	Electric drill Drill bits 3mm (1/8")	Deep Socket Wrench
-----------------	--------------------------	------------------	------------------	-------------------	--	------------------------

Parts




Solid Brick Wall\Hollow Brick Wall\Concrete wall and cement wall require the following tools: (drilling steps on pages10-12)

Tools


Tape measure 	levelling instrument 	Speed Square 	Marking tools 	Electric drill Drill bits 3mm (1/8") 15mm (1/2")	Deep Socket Wrench
------------------	--------------------------	------------------	-------------------	---	------------------------

Parts




2 Pick Your Door Openg Direction

Open the door to the right




Open the door to the left



3 Check for level floor and center of track level


IMPORTANT!

- ★ To ensure that the door opens and closes prorerly, use a level to check the floor and center of track are level before installing and measuring.
- ★ Tracks that are not level can cause sliding doors to jam, or door panels to slide sideways





Step1 Tracks Connection


① Lay the tracks flat as shown and start splicing them together




② Prepare two pieces of wood and ③ packaging




Flatten the tracks and squeeze the two tracks towards the middle




Put  into the hole



 Place a piece of wood on top of use a hammer to secure it into the track



Then the track is connected firmly




Step 2: Install the track ("Plasterboard Wall" and "Wood Frame Wall" installation process in P7-P9; "Concrete Wall" please check P10~P12)

The track installation process for gypsum board wall and wood framed walls is as follows.


(The header board needs to be prepared by yourself.)

- ① Before installation, please "Prepare a Backboard" (please refer to the following suggested backboard size) and some nails needed to fix the backboard.


Same length as the track



- ② After the backboard is ready, please determine the installation position.




- ③ Use the Stud Finder to determine the load bearing position and install the backboard.




The track installation process for gypsum board wall and wood framed walls is as follows.

- ④ Put the track on the Centre of Track and mark the position




- ⑤ Drill deep 50mm (2") holes with 3mm (1/8") power drill




The track installation process for gypsum board wall and wood framed walls is as follows.

⑥ Packing ③ parts installation position (no need to use wood nails)




⑦ Track installation completed




The track installation process for Solid Brick Wall\Hollow Brick Wall\Concrete wall and cement wall is as follows.

①Refer to the picture instructions to locate the track mounting position and mark the location of the punched holes.




② Drill deep 50mm(2") holes with 15mm(19/32")power drill.




The track installation process for Solid Brick Wall\Hollow Brick Wall\Concrete wall and cement wall is as follows.


- ③ Take out the wood plugs from ③ and use a hammer to smash them into the hole.



- ④ Refer to the dimensions in the attached table and proofread the dimensions again with a tape measure (Mark the location of the punch on the wood nails.)




- ⑤ Drill deep 50mm(2") holes with 3mm($\frac{1}{8}$ ") power drill




The track installation process for Solid Brick Wall\Hollow Brick Wall\Concrete wall and cement wall is as follows.

⑥ Packing C parts installation position




⑦ Track installation completed




Step3 Bottom Slotting of Door Panel and Hangers Installation


① Slot according to size at the bottom of the door.




② Mark the drilling position





③ Use a 3mm ($\frac{1}{8}$ ") diameter drill bit to drill 50mm (2") deep holes on the top of the door. Fix the hanger ④ with ⑤ parts




④ Hang the door on the track



Step4 Install Anti-slip Blocks and Floor Guide



Step5 Install Door Stoppers



Adjust to the appropriate position and fixed with an allen key

